

SERVICE BULLETIN #7

RE: LUBRIPLATE PORTABLE TOOL GREASE

Little Beaver, Inc., recommends the use of Lubriplate portable tool grease for the flexible shaft on all Little Beaver power units' flexible shaft assembly. This grease may be purchased through the factory. It is available in tube form and may be purchased as a single unit or case. A case includes 12 tubes of grease.

For maximum dependability, the flexible core should be removed, cleaned and lightly greased every 50 to 100 hours of use. Please refer to the parts manual for greasing instructions.

PART #9070-L \$ 8.00

PART #9070-LCS (CASE) \$ 88.00

FOR MORE INFORMATION CONTACT:

LITTLE BEAVER, INC.

P. O. Box 840, Livingston, Texas 77351

PH: 936/327-3121 or Fax: 936/327-4025

*PRICES ARE F.O.B. LIVINGSTON, TEXAS U.S.A.
EFFECTIVE: JANUARY 1, 2005*